

STEADICAM® STEADIMATE

Arm & Vest Adapter for Motorized Gimbals

HOW IT WORKS:

Attach the Steadimate adapter to the handlebar of the motorized gimbal → Balance the Steadimate System → Connect your Arm and Vest → Enjoy the operating benefits!

THE BENEFITS:

Take the load off the operator's arms for longer durations of operating without the fatigue.


Effortless tilting via the pivot on the Steadimate.

Increased stability & z-axis stabilization for the smoothest shot possible.

Quick interchangeable use from handheld operation to Steadimate operation.



COMPATIBILITY:



Motorized Gimbals with handlebars that are 25 mm, 25.5 mm, or 30 mm in diameter.

The Steadimate comes standard with a post block and balance pin that fit arms with 1/2" posts. Operators can purchase accessories that adapt the Steadimate to fit arms with 5/8" and 3/4" posts.

The weight capacity for the Steadimate depends on the weight capacity of the motorized gimbal, arm, & vest being used. For operators who already own an arm & vest, the Steadimate can be purchased on its own. For operators in need of a complete kit, Tiffen offers Steadimate Systems in two weight classes:

Steadimate System with the A-15 Arm [15 lb / 6.8 kg capacity] & SOLO Vest
Steadimate System with the A-30 Arm [30 lb / 13.6 kg capacity] & Zephyr Vest

